


## NC894DKB/M

## Mk4 Isolatable Monitoring Point


Approved Document No: DNU8944100 Rev 1



BASIC CONFIGURATION FOR NC894DKB/M ISOLATABLE MONITORING POINT ONLY

CONFIGURATION FOR ISOLATING
OTHER CALL POINTS FROM
NC894DKB/M MONITORING POINT

**KEY TO DIAGRAMS**: **D** = Door Monitoring Point. **C** = Standard Call Point.



- For use with normally closed switch(es), make sure option link PLK1 is fitted and connect switch(es) (magnetic contacts) in series with NC & T.
- For use with normally open switch(es), make sure option link PLK1 is removed and connect switch(es) in parallel with NO & T.
- To disable monitoring, turn keyswitch to isolate.

You cannot use NO & NC switches at the same time.